

CALCULATIONS FOR TWO-STATION METHOD

A = amount settled in array. Number of particles, d'less.

$$\frac{dA}{dt} = \frac{C' V_s}{h} (1 - E_r') \phi V_A$$

Primes denote calculations specific to array

$$\frac{dA}{dt} = \frac{C' V_s}{h} (1 - E_r') \phi_0 e^{-kt} V_A$$

k is measured from whole-experiment removal rate.

$$k' = \phi_0 \frac{C' V_s}{h} (1 - E_r') V_A$$

$[\frac{1}{L^3} \frac{L}{T} L^3] = [\frac{1}{T}]$

$$\frac{dA}{dt} = k' e^{-kt}$$

$$u = -kt \quad du = -k dt$$

$$A = \int_0^T k' e^{-kt} dt = \left[-\frac{k'}{k} e^{-kt} \right]_0^T = -\frac{k'}{k} e^{-kT} + \frac{k'}{k} = \frac{k'}{k} (1 - e^{-kT})$$

$$k' = \frac{A}{(1 - e^{-kT})}$$

T = total time of experiment

At any given sampling time,
change in # concentration

$$\left(\frac{d\phi}{dt} \right)_{\text{settling}} = \frac{-k' \bar{\phi}}{\phi_0 V_A}$$

where $\bar{\phi}$ is the number concentration averaged over 2 stations.

Across the sample volume —

A_c = amount removed due to capture (# particles / volume) u = velocity

L = length (streamwise) of sample array V_A = volume of array

$$A_c = \phi_{\text{upstream}} - \frac{k' \phi_{\text{upstream}}}{V_A \phi_0} \frac{\text{length of array}}{\text{velocity}} \phi_{\text{downstream}}$$

$$\eta \bar{\phi} \frac{L}{h} d_c I_c^* = A_c$$

(from Fanning)

ϕ = depth-avg particle concentration, #/L³

$$\left[\frac{L}{L^3} \frac{L}{L} \right]$$

* Based on volume of array (array = test section)

TWO-STATION METHOD, IN TERMS OF BULK MASS CONC.

A_m = Amount settled by mass A = # particles
particle density

Get A from settling traps

$$k' = \frac{kA}{(1-e^{-kT})}$$

$$A_m = \frac{4}{3} A \rho_b \pi \left(\frac{d}{2}\right)^3 = \frac{1}{6} A \rho_b \pi d^3$$

mass-weighted mean
 d = sediment diameter

(different from d_c collar/stem diameter)

How to calculate A?
- from LISST volume concentration?
or use sed. traps to get A_m directly?

\bar{C} = concentration averaged @ two stations.
 C_c = concentration removed due to capture
 C_0 = mass concentration @ time 0.

$$k' = \frac{6 k A_m}{\rho_b \pi d^3 (1-e^{-kT})}$$

C = mass concentration

$$C_c = C_{upstream} - \frac{k' C_{upstream} L}{u C_0} - C_{downstream}$$

$$C_c = \eta \bar{C} L d_c I_c \quad \text{Settling}$$

* Based on volume of array

Assuming η is capture efficiency? total density (volume of test section)

HOW TO CALCULATE d FROM LISST DATA, ASSUMING NON-FLOCCULATED PARTICLES:

Mass of a particle = $\rho_b \cdot \frac{4}{3} \pi D^3$

D = size class-specific diameter

$$d = \frac{\sum_i C_{vi} \rho_b d_i}{\sum_i C_{vi} \rho_b}$$

C_{vi} = volumetric concentration ($\frac{\text{vol sed}}{\text{vol sample}}$)
 i = size class
 n = total # size classes

SINGLE-STATION METHOD

$$\frac{d\bar{C}}{dt} = - \left[\frac{C_{vs}}{h} (1-\epsilon_r) + \eta' u d_c I_c \right] \bar{C} = -k \bar{C}$$

Get this from no-draw experiments